





4. Place the window into the opening on top of the shims and put a level on the sill to make sure the sill is level and not crowned.
5. Once the sill is level, loosely install the installation screws into the pre-drilled holes in the frame. Check the frame for square by measuring diagonally from corner to corner. On a double hung, adjust the alignment screws until the jambs are plumb from top to bottom. On a slider, use shims to plumb the jambs. Now finish tightening the installation screws taking care not to distort the frame. (On a slider or wide double hung, shim the head of the frame if necessary so that it is level and install an installation screw. Wider windows might require more than one screw).
6. Recheck the frame for square and plumb and make sure the sashes operate and lock properly. (Slider sashes should lift out easily). Also make sure all weatherstripping is making contact and the reveals between the sash and frame are even.
7. On the outside, cut the sill trim to fit between the blind stops and tap it into the accessory groove. (If a slider is being installed on a sloped sill, shim the outside of the frame to support the weight of the sash, and then install the sill trim).
8. Caulk around the perimeter of the frame on the outside with an approved sealant. Where needed, trim and cap. Do not cover the weep holes on a slider or fixed window.
9. Finally, finish off the inside of the window.